



Reference Manual

Volume IV

CODE V Version 10.2

December 2009

OPTICAL RESEARCH ASSOCIATES

3280 East Foothill Boulevard, Suite 300

Pasadena, California 91107

Phone: (626) 795-9101

Fax: (626) 795-0184

E-mail: service@opticalres.com

<http://www.opticalres.com>

The information in this document is subject to change without notice and should not be construed as a commitment by Optical Research Associates (ORA®). ORA assumes no liabilities for any errors that may appear in this document.

The software described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license. CODE V output listed and plotted may vary from version to version, and from platform to platform.

Copyright© 2009 by Optical Research Associates
All rights reserved

Proprietary Software Notification

CODE V® is the proprietary and confidential property of ORA and/or its suppliers. It is licensed for use on the designated equipment on which it was originally installed and cannot be modified, duplicated, or copied in any form without prior written consent of ORA. If supplied under a U.S. Government contract the following also applies:

Restricted Rights Legend

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 or in subparagraph (c) of the Commercial Computer Software - Restricted Rights clause at FARS 52.227-19.

CODE V, ORA, Global Synthesis, and *LightTools* are registered trademarks and Macro-PLUS and Worksheet Buffer are trademarks of Optical Research Associates. Other trademarks or marks are the property of their respective companies.

CODE V 10.2 REFERENCE MANUAL

Volume I Contents

Preface	xxi
Chapter 1. Operating CODE V	
Overview / Introduction	1-9
Getting Help with CODE V	1-16
Starting and Exiting CODE V	1-21
Running CODE V	1-27
Exploring the CODE V Workspace	1-46
Printing and Plotting in CODE V	1-75
File Naming Conventions and Usage in CODE V	1-88
Creating User-Defined Features	1-96
Parallel Processing Support for Local and Global Optimization	1-158
Dynamic Memory	1-176
Chapter 2. The CODE V Lens Data Manager	
CODE V Lens Data Manager (LDM) Overview	2-3
Creating a New Lens	2-20
Opening, Saving, and Exporting Lenses	2-23
Optical Suppliers' Lens Catalogs	2-31
Using ORA's Patent Database Lenses	2-43
Chapter 3. Entering System Data	
Entering System Data	3-5
Creating Wavelength Specifications	3-6
Creating the Pupil Specification	3-12
Creating the Field Specification	3-17
Specifying Reference Ray Aiming	3-27
Specifying Vignetting	3-37
Specifying Through-Focus Data	3-42
Specifying Afocal Data	3-46
Creating Astigmatic Objects	3-54
Defining Output Fiber Location	3-56
Defining Tolerance Controls	3-60
Specifying System Settings	3-65
Chapter 4. Entering Surface Shape and Position	
Entering Surface Shape and Position	4-9
Command Line Shorthand Surface Entry	4-12
Inserting, Deleting, and Copying Surfaces	4-16
Defining Spherical Surfaces	4-31
Defining Thickness and Separation	4-35
Entering Solves	4-38
Defining Pickups	4-52
Using Surface Labels	4-61
Creating Surface Groupings	4-63
Defining Non-Spherical Surfaces	4-67

Defining Conic/Asphere Surfaces	4-72
Defining Cylindrical Surfaces	4-75
Defining X-Toroid Surfaces	4-77
Defining Y-Toroid Surfaces	4-78
Defining Thermal Gradient Surfaces.....	4-79
Defining Spline Asphere Surfaces.....	4-81
Defining Anamorphic Asphere Surfaces	4-84
Defining Lens Module Surfaces	4-86
Defining User-Defined Surfaces.....	4-93
Defining Special Surfaces.....	4-97
Defining Diffractive Surfaces.....	4-114
Defining Linear Grating Properties	4-120
Defining Phase Function Properties	4-124
Defining Holographic Optical Element Properties.....	4-129
Defining Array Elements.....	4-139
Defining Parallel Arrays Using a Regular Grid.....	4-141
Defining General Element Arrays	4-143
Defining Polynomial Arrays.....	4-145
Using Array Elements.....	4-147

Chapter 5. Defining Lens Materials

Defining Lens Materials	5-5
Designating Glasses on Surfaces	5-6
Using Pre-stored Glass Catalogs	5-14
Using Fictitious Glasses	5-18
Using Reflecting Surfaces	5-25
Using Private Catalog Glasses.....	5-26
Defining Other Glass Properties.....	5-37
Defining Gradient Index Materials (GRIN)	5-44
Using Gradient Index Materials (GRIN) General Commands	5-45
Defining SELFOC Gradients.....	5-50
Defining Axial Gradients.....	5-52
Defining University of Rochester Gradients	5-54
Defining Luneberg Lens Gradients	5-56
Defining Spherical Gradients	5-58
Defining Maxwell's Fisheye Gradients.....	5-60
Defining User-Defined Gradients.....	5-62
Gradient Index Materials (GRIN) Definitions and Examples	5-65

Volume II Contents

Chapter 6. Defining Tilts and Decenters

Defining Tilts and Decenters	6-5
Tilt and Decenter Definitions	6-8
Decenter Types	6-16
Specifying Global References	6-22
Tilts and Decenters: System Considerations	6-26
Defining Non-Sequential Surfaces and Elements	6-29
Defining Non-Sequential Elements	6-30
Defining Non-Sequential Surfaces	6-34
Implementation of NS Ray Tracing	6-45
Cautions About Non-Sequential Surfaces	6-48
Getting Started Examples for Non-Sequential Surfaces	6-50
References	6-62

Chapter 7. Defining the Lens Element Structure

Defining the Lens Element Structure	7-3
Defining Apertures	7-4
Defining First Surface Mirror Substrates	7-25
Defining Coating and Cement Data	7-28

Chapter 8. Defining Tolerances

Defining Tolerances	8-3
Description of Tolerances	8-44

Chapter 9. Defining Polarization

Defining Polarization	9-3
Activating Polarization Ray Tracing	9-4
Specifying the Polarization State - Source Model	9-5
Specifying the Polarization State - Polarization Coordinate System	9-6
Specifying the Polarization State - Geometrical Representation	9-7
Specifying the Polarization State - Jones Vector Representation	9-8
Specifying the Polarization State - Stokes Parameters Representation	9-9
Assigning Polarization Operators to a Surface	9-10
Defining Pseudo-Birefringent Materials	9-13
Polarization - Usage	9-16
Examples of Polarization Output	9-31

Chapter 10. Defining Pupil Apodization and Surface Deformations

Defining Pupil Apodization	10-3
Defining Interferometric Deformations and Intensity Apodization	10-9
Attaching INT Data to a Surface, Entrance Pupil, or Exit Pupil	10-11
Defining Orientation of INT Data	10-15
Usage of Interferometric Data in CODE V	10-19
Usage of Intensity Apodization Data in CODE V	10-23
Interferogram Coordinate Systems and Sign Conventions	10-24
Miscellaneous Technical Issues	10-26
INT File Format	10-30
INT File Sample Output	10-34

Interfacing to Commercial Interferometers	10-36
NASTRAN-Generated Deformations.....	10-37
Chapter 11. Defining Zoom Systems	
Defining Zoom (Multi-Configuration) Systems	11-3
Chapter 12. Defining Variables and Control Codes	
Defining Variables and Control Codes	12-3
Chapter 13. Deleting Data	
Deleting Data	13-3
Chapter 14. Transforming and Calculating Lens Data	
Transforming and Calculating Lens Data	14-3
Chapter 15. Displaying and Reviewing Lens Data	
Displaying and Reviewing Lens Data	15-5
Chapter 16. Performing Quick LDM Evaluations	
Performing Quick LDM Evaluations	16-3

Volume III Contents

Chapter 17. AUT - Automatic Design

AUT - Automatic Design	17-5
When to Use the Automatic Design Option	17-5
Automatic Design Default Operation	17-5
Parallel Processing Support	17-6
Using the Automatic Design Option	17-6
Command Mnemonics	17-7
Defining the Error Function Content	17-8
Defining Specific Constraints	17-10
Specifying Constraint Mode Settings	17-25
Defining User-Defined Constraints	17-27
Defining User-Defined Reference Rays	17-29
Defining General Constraints	17-30
Specifying Exit Controls	17-34
Specifying Output Controls	17-35
Specifying the Error Function Definitions and Controls	17-37
Specifying Gaussian Beam (BEA) and Beam Propagation (BPR) Controls	17-47
Specifying Error Function Weights	17-50
Specifying Through-focus Optimization Controls	17-52
Specifying the MTF Error Function Controls	17-54
Specifying a User-Defined Error Function	17-57
Output to Macro-PLUS	17-60
Discussion of Input and Computations	17-60
Description of Output	17-85
Technical Notes	17-95

Chapter 18. Diagnostic Analyses

ANA - First/Third Order Analysis	18-7
When to Use the First/Third Order Analysis Option	18-7
First/Third Order Analysis Default Operation	18-7
Command Mnemonics	18-7
Defining First/Third Order Analysis Mode/Output Controls	18-8
Listing Surface-by-Surface Ray Coordinates	18-10
Discussion of Input and Computations	18-11
Description of Output	18-13
Technical Notes	18-22
BEA - Gaussian Beam Trace.....	18-27
When to Use the Gaussian Beam Trace Option	18-27
Default Operation	18-27
Command Mnemonics	18-27
Defining Input Beam Settings	18-28
Defining Color Display Settings	18-29
Defining Output Controls	18-31
Discussion of Input and Computations	18-32
Description of Output	18-33
Technical Notes	18-38

CAT - Catseye Plot	18-39
When to Use the Catseye Plot Option	18-39
Default Operation	18-39
Command Mnemonics	18-39
Defining Catseye Plot Settings	18-39
Discussion of Input and Computations	18-40
Description of Output	18-41
FIE - Field Curves	18-43
When to Use the Field Curves Option	18-43
Default Operation	18-43
Command Mnemonics	18-43
Defining Field Curves Analysis Settings	18-43
Discussion of Input and Computations	18-46
Description of Output	18-48
Technical Notes	18-56
FIO - Paraxial Ray Trace.....	18-59
Performing First-Order Calculations	18-59
FMA - Field Map	18-63
When to Use the Field Map Option	18-63
Default Operation	18-63
Command Mnemonics	18-63
Defining Field Display Settings	18-64
Creating the Field Description	18-66
Defining the Field Map Computation	18-68
Defining Field Map Output	18-70
Using Bragg Diffraction Efficiency Analysis	18-71
Discussion of Input and Computations	18-75
Description of Output	18-79
Technical Notes	18-88
FOO - Footprint Plot.....	18-91
When to Use the Footprint Plot Option	18-91
Default Operation	18-91
Command Mnemonics	18-91
Defining Computation Controls	18-92
Defining Plot Controls	18-94
Defining Graphics Settings	18-95
Defining Plot Symbols	18-97
Defining Special Controls	18-100
Discussion of Input and Computations	18-104
Description of Output	18-106
FOV - Biocular Field of View Plot	18-113
When to Use the Biocular Field of View Plot	18-113
Default Operation	18-113
Command Mnemonics	18-114
Defining Computation and Plotting Controls	18-114
Defining Graphics Controls	18-116
Defining Special/Multi-mode Projector Controls	18-118
Discussion of Input and Computations	18-119
Description of Output	18-121
PMA - Pupil Map.....	18-127
When to Use the Pupil Map Option	18-127
Default Operation	18-127
Command Mnemonics	18-127
Defining Display Settings	18-127

Defining Computation Controls	18-130
Defining Output Controls	18-132
Defining Plotting Controls	18-134
Defining Color Display Settings	18-136
Defining Zernike Coefficients Controls	18-138
Defining a Perturbed Wavefront	18-139
Discussion of Input and Computations	18-140
Description of Output	18-146
Technical Notes	18-152
RIM - Ray Aberration Curves/OPD Aberration Curves	18-155
When to Use the Ray Aberration Curves/OPD Aberration Curves Option	18-155
Default Operation	18-155
Command Mnemonics	18-155
Defining Plot Controls	18-156
Defining Wavelength/Color Settings	18-158
Discussion of Input and Computations	18-159
Description of Output	18-160
RSI/SIN - Real Ray Trace	18-165
Performing Real Ray Traces	18-165
THO - Third Order Aberrations	18-181
Performing Third-Order Aberrations	18-181
Macros to Perform Diagnostic Analyses	18-183
Distortion Grid (DIST) Macro	18-183
Fifth-Order Aberrations (FORDER) Macro	18-183
Lateral Color Plot (LATCOLOR) Macro	18-183

Chapter 19. Geometrical and Diffraction Analyses

BIO - Biocular Analysis	19-9
When to Use the Biocular Analysis Option	19-9
Default Operation	19-9
Command Mnemonics	19-9
Defining Display Settings	19-10
Defining Units Settings	19-13
Defining Graphics/Output Settings	19-15
Defining Non-uniform Grid Settings	19-17
Defining Multi-Module Display Settings	19-19
Discussion of Input and Computations	19-21
Description of Output	19-22
BPR - Diffraction-Based Beam Propagation	19-37
When to Use the Diffraction-Based Beam Propagation (BPR) Option	19-37
Default Operation	19-37
Command Mnemonics	19-38
Defining the Input Beam	19-38
Defining Computational Controls	19-41
Defining Output Controls	19-44
Defining Plotting Controls	19-45
Defining Color Display	19-47
Discussion of Input and Computations	19-48
Description of Output	19-52
Troubleshooting	19-65
Technical Notes	19-71

BSP - Beam Synthesis Propagation	19-77
When to Use BSP	19-78
Using the Pre-Analysis Feature	19-79
Default Operation	19-79
Command Mnemonics	19-79
BSP Process Summary	19-80
Configuring and Running BSP	19-81
Discussion of Input and Computations	19-116
Description of BSP Output	19-144
Pre-Analysis Troubleshooting	19-176
CEF - Fiber Coupling Efficiency	19-179
When to Use the Fiber Coupling Efficiency (CEF) Option	19-179
Energy Loss Factors that Impact Fiber Coupling Efficiency	19-179
Default Operation	19-181
Command Mnemonics	19-181
Defining Fiber Specifications	19-181
Defining the Output Fiber Position	19-183
Creating the Beam Definition	19-183
Defining Computation Controls	19-185
Defining Analysis Selection Settings	19-187
Discussion of Input and Computations	19-189
Description of Output	19-194
Technical Notes	19-205
GDE - Geometrical Detector Analysis	19-207
When to Use the Geometrical Detector Analysis Option	19-207
Default Operation	19-207
Command Mnemonics	19-207
Defining Geometrical Detector Analysis Settings	19-207
Discussion of Input and Computations	19-209
Description of Output	19-210
GLS - Geometrical Line Spread Function	19-211
When to Use the Geometrical Line Spread Function Option	19-211
Default Operation	19-211
Command Mnemonics	19-211
Defining Geometrical Line Spread Function Settings	19-212
Discussion of Input and Computations	19-212
Description of Output	19-213
IMS - 2D Image Simulation	19-215
When to Use the 2D Image Simulation Option	19-215
Default Operation	19-215
Command Mnemonics	19-215
IMS Procedure Overview	19-216
Launching IMS from the CODE V Toolbar	19-216
Defining the Input Object	19-216
Defining Point Spread Function (PSF) Controls	19-219
Defining Color Controls	19-222
Defining Output Controls	19-225
Using the Image Simulation File Viewer	19-228
Example Input Object Files Provided with 2D Image Simulation	19-230
Discussion of Input and Computations	19-231
Description of Output	19-236
Technical Notes	19-245

LSF - Diffraction Line Spread Function.....	19-253
When to Use the Diffraction Line Spread Function Option	19-253
Default Operation	19-253
Command Mnemonics	19-253
Defining Diffraction Line Spread Function Settings	19-253
Discussion of Input and Computations	19-257
Description of Output	19-261
MTF - Modulation Transfer Function, Geometrical and Diffraction.....	19-263
When to Use the Modulation Transfer Function (MTF) Option	19-263
Default Operation	19-263
Command Mnemonics	19-263
Defining Frequency/Calculation Settings	19-264
Defining Image Motion Settings	19-266
Defining Plotting Controls	19-267
Discussion of Input and Computations	19-269
Description of Output	19-270
Technical Notes	19-279
PAR - Partial Coherence, 1D and 2D.....	19-281
When to Use the Partial Coherence (PAR) Option	19-281
Default Operation	19-281
Command Mnemonics	19-281
Defining Source Coherence Settings for 1D Partial Coherence	19-282
Defining Computation Controls for 1D Partial Coherence	19-285
Defining Plot Settings for 1D Partial Coherence	19-287
Defining Object Settings for 1D Partial Coherence	19-289
Defining Output Controls for 1D Partial Coherence	19-292
Defining Perturbed Wavefront Settings for 1D Partial Coherence	19-293
Linewidth Computation Controls for 1D Partial Coherence	19-293
Defining Source Coherence Settings for 2D Partial Coherence	19-298
Defining Computation Controls for 2D Partial Coherence	19-302
Defining Output Controls for 2D Partial Coherence	19-303
Defining Color Display Controls for 2D Partial Coherence	19-305
Defining Object Parameters for 2D Partial Coherence	19-307
Defining Wavefront Perturbation Settings for 2D Partial Coherence	19-309
Discussion of Input and Computations	19-310
Description of Output	19-319
Technical Notes	19-336
PSF - Point Spread Function.....	19-339
When to Use the Point Spread Function Option	19-339
Default Operation	19-339
Command Mnemonics	19-340
Defining Analysis Type Settings	19-340
Defining Computation Controls	19-342
Defining Settings for Two Point Sources	19-344
Defining Output Controls	19-346
Defining Color Display Settings	19-349
Defining Detector Energy Settings	19-351
Defining Encircled Energy Settings	19-353
Defining Wavefront Perturbation Settings	19-356
Discussion of Input and Computations	19-357
Description of Output	19-367
Technical Notes	19-372

QUA - Quadrant Detector Analysis	19-375
When to Use the Quadrant Detector Analysis Option	19-375
Default Operation	19-375
Command Mnemonics	19-375
Defining Quadrant Detector Analysis Settings	19-376
Discussion of Input and Computations	19-377
Description of Output	19-378
RAD - Radial Energy	19-381
When to Use the RAD (Radial Energy) Option	19-381
Default Operation	19-381
Command Mnemonics	19-381
Defining Radial Energy Settings	19-381
Discussion of Input and Computations	19-383
Description of Output	19-385
SPO - Spot Diagram	19-389
When to Use the Spot Diagram Option	19-389
Default Operation	19-389
Command Mnemonics	19-389
Defining Output Controls	19-390
Defining Computation Controls	19-393
Defining Annotations and Overlays	19-396
Discussion of Input and Computations	19-398
Description of Output	19-401
Technical Notes	19-407
WAV - Wavefront Analysis	19-409
When to Use the Wavefront Analysis Option	19-409
Default Operation	19-409
Command Mnemonics	19-409
Defining Wavefront Analysis Settings	19-410
Discussion of Input and Computations	19-411
Description of Output	19-412
Technical Notes	19-414

Chapter 20. Tolerancing

TOR - Wavefront Differential Tolerancing	20-5
When to Use the Wavefront Differential Tolerancing (TOR) Option	20-5
Default Operation	20-6
Command Mnemonics	20-6
Defining Performance Measures	20-6
Defining Zernike Polynomial Controls	20-10
Defining Computation Controls	20-12
Defining Output Controls	20-13
Defining Compensation Controls	20-17
Defining Probability Density Functions	20-18
Defining Tolerance Limits	20-21
Linewidth Computation Controls for 1D Partial Coherence Tolerancing	20-23
Discussion of Input and Computations	20-29
Description of Output	20-46
Technical Notes	20-65

TOD - Distortion Tolerancing	20-73
When to Use the Distortion Tolerancing (TOD) Option	20-73
Default Operation	20-73
Command Mnemonics	20-73
Defining Performance Measures	20-74
Defining Controls	20-75
Discussion of Input and Computations	20-76
Description of Output	20-77
Technical Notes	20-79
TOL - Primary Aberration-Based Tolerancing	20-81
When to Use the Primary Aberration-Based Tolerancing (TOL) Option	20-81
Default Operation	20-81
Command Mnemonics	20-82
Defining Add-on Tolerance	20-82
Defining Output Table Selection	20-82
Defining Controls	20-83
Defining Functions and Output Commands	20-84
Discussion of Input and Computations	20-86
Description of Output	20-91
Technical Notes	20-100
User-Defined Tolerancing	20-107
Lens Setup (Tolerances and Compensators)	20-108
Supporting Macros	20-108
Finite Differences Tolerancing (TOLFDIF Macro) Usage	20-110
Monte Carlo Tolerancing (TOLMONTE Macro) Usage	20-113
Supporting Macro Descriptions	20-118

Chapter 21. Fabrication Support

ALI - Alignment Optimization	21-5
When to Use the Alignment Optimization (ALI) Option	21-5
Preparation for Running the Alignment Option	21-6
Default Operation	21-6
Command Mnemonics	21-7
Data Input Overview	21-7
Defining the Interferogram	21-8
Fitting the Interferograms to the Exit Pupil	21-10
Null Test Analysis: Converting Non-normal Null Test Interferograms to Normal Interferograms	21-12
Defining a Null Test Analysis	21-13
Defining Computation Controls	21-15
Discussion of Input and Computations	21-16
Description of Output	21-18
Technical Notes	21-25
CAM - CAM Calculation	21-27
When to Use the CAM Calculation (CAM) Option	21-27
Default Operation	21-27
Command Mnemonics	21-27
Zoomed Lens - Interpolating Between Zoom Positions	21-28
Dezoomed Lens - Stepping and Optimizing Each Increment	21-29
Discussion of Input and Computations	21-31
Description of Output	21-32

COS - Cost Analysis	21-37
When to Use the Cost Analysis (COS) Option	21-37
Default Operation	21-37
Command Mnemonics	21-37
Defining Blocking Parameters	21-37
Discussion of Input and Computations	21-39
Description of Output	21-40
CXP - CAD Export	21-43
When to Use the CAD Export (CXP) Option	21-43
Default Operation	21-43
Command Mnemonics	21-43
Defining Export Controls	21-44
Defining Model Controls	21-45
Defining Rays	21-47
Discussion of Input and Computations	21-50
Description of Output	21-52
FAB - Fabrication Data	21-55
When to Use the Fabrication Data (FAB) Option	21-55
Default Operation	21-55
Command Mnemonics	21-55
Defining Output Controls	21-56
Defining Aspheric Sag Data	21-57
Displaying Interferogram Data	21-59
Displaying Color Interferogram Data	21-61
Discussion of Input and Computations	21-64
Description of Output	21-65
LTE - <i>LightTools</i> Export	21-75
When to Use the <i>LightTools</i> Export (LTE) Option	21-75
Default Operation	21-75
Command Mnemonics	21-75
Defining Options for Exporting to <i>LightTools</i>	21-75
Discussion of Input and Computations	21-77
Description of Output	21-80
TES - Test Plate Fitting	21-83
When to Use the Test Plate Fitting (TES) Option	21-83
Default Operation	21-83
Command Mnemonics	21-83
Defining Computational Controls	21-84
Defining Test Plate Data	21-85
Discussion of Input and Computations	21-87
Description of Output	21-89
WEI - Weight Analysis	21-93
When to Use the Weight Analysis (WEI) Option	21-93
Default Operation	21-93
Running the WEI Option	21-94
Discussion of Input	21-94
Description of Output	21-94

Volume IV Contents

Chapter 22. Environmental Change

ENV - Environmental Change	22-3
When to Use the Environmental Change (ENV) Option	22-3
Default Operation	22-4
Command Mnemonics	22-4
Using the ENV Option with Zoomed Systems	22-4
Defining System Pressure/Temperature Settings	22-5
Defining Expansion Constants	22-7
Defining Pressure/Temperature Gradients	22-10
Discussion of Input and Computations	22-12
Description of Output	22-16
Technical Notes	22-21

Chapter 23. Systems Analysis and Multilayer Design

GHO - Ghost Image Analysis.....	23-5
When to Use the Ghost Image Analysis (GHO) Option	23-5
Default Operation	23-5
Command Mnemonics	23-5
Defining Ghost Image Analysis Parameters	23-6
Discussion of Input and Computations	23-7
Description of Output	23-7
LUM - Illumination Analysis	23-13
When to Use the Illumination Analysis (LUM) Option	23-13
Default Operation	23-13
Command Mnemonics	23-13
Defining Analysis Controls	23-14
Defining Output Controls	23-16
Defining Color Display	23-17
Defining Receiver Definition	23-18
Defining Source Definition	23-19
Defining Data Export Controls	23-22
Discussion of Input and Computations	23-23
Description of Output	23-33
MUL - Multilayer Coating Design and Analysis.....	23-47
When to Use the Multilayer Coating Design and Analysis (MUL) Option	23-47
Default Operation	23-47
Command Mnemonics	23-47
Defining Choice of Sub-option	23-48
MDA Sub-option	23-49
MCH Sub-option	23-52
MAU Sub-option	23-54
MTO Sub-option	23-56
MPL Sub-option	23-56
MLI Sub-option	23-57
Immediate Commands	23-57
Discussion of Input and Computations	23-58
Description of Output	23-59
Technical Notes	23-63

NAR - Narcissus Analysis	23-67
When to Use the Narcissus Analysis (NAR) Option	23-67
Default Operation	23-67
Command Mnemonics	23-67
Defining Narcissus Parameters	23-68
Defining Real-ray/Scan Parameters	23-69
Discussion of Input and Computations	23-70
Description of Output	23-72
Technical Notes	23-77
SPE - Spectral Analysis	23-81
When to Use the Spectral Analysis (SPE) Option	23-81
Default Operation	23-81
Command Mnemonics	23-81
Defining Cascading of Responses/User-defined Responses	23-82
Defining Plotting/Listing Controls	23-82
Generating Spectral Weights and Wavelengths	23-84
Discussion of Input and Computations	23-84
Description of Output	23-90
SSS - Solar Simulator System	23-95
When to Use the Solar Simulator System (SSS) Option	23-95
Default Operation	23-98
Command Mnemonics	23-98
Labeling of Output	23-98
Defining Lamp Array	23-98
Defining Mixer Array	23-99
Performing Simulation	23-100
Defining Plotting	23-100
Performing Irradiance Scans	23-101
Performing Collimation Computation	23-102
Discussion of Input and Computations	23-102
Description of Output	23-105
TRA - Transmission Analysis	23-113
When to Use the Transmission Analysis (TRA) Option	23-113
Default Operation	23-113
Command Mnemonics	23-113
Defining Transmission Analysis Controls	23-114
Discussion of Input and Computations	23-115
Description of Output	23-117
Technical Notes	23-122

Chapter 24. Defaults and Utilities

Command Processing	24-5
Command Mnemonics	24-5
Command Processing	24-6
Option Processing and Exit	24-7
Command Mnemonics	24-7
Option Processing and Exit	24-7
Option Intervention	24-8
Usage	24-8
Option Intervention and Emergency Exit	24-8

Immediate Commands/Defaults	24-9
Default Operation	24-9
Command Mnemonics	24-9
Data Input Description	24-10
Defining the Number of Processors for Parallel Processing	24-11
Defining User Helps - Command Line Only	24-12
Defining Program Settings	24-12
Defining Configuration - Optical	24-14
Defining Configuration - Mathematical	24-15
Defining Configuration - Graphics	24-16
Defining Configuration - I/O	24-19
Defining I/O File Selection and Display	24-22
Defining Control of Windows	24-25
Restoring Standard Lens	24-26
Enabling or Disabling File Versioning	24-27
Defining Macro-PLUS Settings	24-27
Using Immediate Commands	24-27
Using DEFAULTS.SEQ	24-40
LIB - File Maintenance.....	24-41
When to Use the File Maintenance (LIB) Option	24-41
Default Operation	24-41
Command Mnemonics	24-41
Definitions	24-41
Defining File Maintenance	24-42
Discussion of Input and Computations	24-43
GLD - Glass Catalog Data.....	24-45
When to Use the Glass Catalog Data (GLD) Option	24-45
Default Operation	24-45
Command Mnemonics	24-45
Definitions	24-45
Defining Glass Catalog Listings	24-46
Discussion of Input and Computations	24-48
CODE V Special Materials Catalog	24-53
UGR - User Graphics.....	24-57
When to Use the User Graphics (UGR) Option	24-57
Default Operation	24-57
Command Mnemonics	24-57
Defining User Graphic Labels	24-58
Defining X,Y Data Sets	24-59
Interfacing with Worksheet Buffer	24-62
Defining Scalar Field Plot	24-62
Defining Vector Field Visualization	24-65
Discussion of Input and Computations	24-67
Description of Output	24-73

Chapter 25. Macro-PLUS

Introduction.....	25-5
Using Macro-PLUS	25-5
Use of Expressions	25-8
User-defined Variables	25-8
Programming with Macro-PLUS	25-10
Debugging Aids	25-19
Miscellaneous Topics	25-20
Things to Remember	25-20

Chapter 25A. Language Reference

User-Defined Elements	25A-7
Predefined Functions	25A-16
Operators	25A-93
Assignment Statement	25A-94
Expressions	25A-95
Control Statements and Commands	25A-97
Input/Output (I/O) Statements	25A-103
Debugging Aids	25A-109
Dialog Box Creation	25A-111

Chapter 25B. Database Reference

Database Items	25B-3
Lens Database Information	25B-4
Optical Database Information	25B-15
Option Database Information	25B-17
Database Item Examples	25B-17
Worksheet Buffer Database	25B-17

Chapter 25C. Macro-PLUS Examples

Introduction	25C-3
Macro-PLUS Examples	25C-5

Chapter 25D. CODE V Supplied Macros

Introduction	25D-9
Generalized Plotting Macros	25D-11
Databases	25D-16
Utilities	25D-18
Components/Apertures	25D-20
Prism Macros	25D-21
Diffraction Optics (Binary Optics) Macros	25D-23
Materials Information	25D-27
Environmental Modeling	25D-28
Optimization Macros	25D-30
1st Order Analysis Macros	25D-32
Geometrical Analysis	25D-35
Diffraction Analysis	25D-37
Photonics Analysis Macros	25D-39
Polarization Analysis Macros	25D-42
Fabrication Support	25D-45
User-Defined Tolerancing	25D-46
User-Defined Features Macros	25D-46
Macros to Define User-Defined Macro Functions	25D-56
Macros to List Various Lens Data	25D-60
Macros to Change Lens Data	25D-61
Animation Macros	25D-62
Illumination Analysis Macros	25D-64
Miscellaneous Macros	25D-65
Microlithography Macros	25D-67
References	25D-71

Chapter 25E. Worksheet Buffer

Introduction	25E-3
Description	25E-4
Worksheet Buffer Commands	25E-12
Worksheet Buffer Database Items	25E-23
Technical Notes	25E-25

Appendix A. Error Messages and Troubleshooting

Error Message Format	A-1
Finding Error and Warning Output	A-2
Controlling Error and Warning Output	A-3
System-Level Errors	A-4
Lens Data Manager Warnings and Errors	A-4
Automatic Design Errors and Warnings	A-6
Analysis Errors and Warnings	A-12
Tolerancing Errors	A-22
Licensing Errors	A-23

Appendix B. Glossary of Optical Terminology**Appendix C. Zernike Polynomials**

About Zernike Polynomials	C-1
Use of Zernike Polynomials in CODE V	C-1
Standard Zernike Polynomials (ZRN)	C-2
FRINGE Zernike Polynomials (ZFR)	C-5
Technical Notes	C-7

Indexes

Option Index	Index-3
Command and Subject Index	Index-5

Contents