

Chapter 18

Diagnostic Analyses

Contents

ANA - First/Third Order Analysis.....	18-7
The First/Third Order Analysis (ANA) option computes simple diagnostic analyses of the optical system including: first-order traces and third-order aberrations, pattern ray traces and wave aberrations, and higher-order ray aberration analyses.	
BEA - Gaussian Beam Trace.....	18-27
The Gaussian Beam Trace (BEA) option traces a “slow” Gaussian beam through an optical system, using propagation equations and calculates at each surface the beam radius, beam orientation, wavefront radius of curvature, waist position and waist radius.	
CAT - Catseye Plot.....	18-39
The Catseye Plot option (CAT) plots the appearance of designated surface edges as viewed on the entrance pupil plane from the object points.	
FIE - Field Curves	18-43
The Field Curves option (FIE) computes and, on request, plots the distortion and astigmatic field curves of the lens as a function of the field; for rotationally asymmetric lenses, a field map of astigmatism is provided. A table of scan linearity is also available.	
FIO - Paraxial Ray Trace.....	18-59
The Paraxial Ray Trace feature (FIO) allows you to perform a first-order ray trace. You can also list first-order system parameters using the First Order Data feature (FIR).	
FMA - Field Map	18-63
The Field Map (FMA) option produces plots of field-dependent performance parameters including distortion, astigmatism, RMS spot diameter, and RMS wavefront error. FMA produces plots for each zoom position. FMA can also produce a table or plot of cumulative diffraction efficiency over the field for all diffractives defined in the system, as well as a table of Bragg diffraction efficiency for systems with volume HOEs.	
FOO - Footprint Plot.....	18-91
Footprint Plot (FOO) provides for clearance checking between adjacent surfaces and for drawing the used portion of designated surfaces.	

FOV - Biocular Field of View Plot	18-113
The Biocular Field of View Plot draws the available field of view (FOV) in azimuth and elevation of the object space for each designated eye point.	
PMA - Pupil Map	18-127
The Pupil Map (PMA) option displays functions in the exit pupil: wave aberrations, pupil intensity, surface codes for ray failure, HOE spatial frequencies, and properties of polarized beams.	
RIM - Ray Aberration Curves/OPD Aberration Curves	18-155
The Ray Aberration Curves option (RIM) plots ray or wave aberrations vs. ray position in the aperture for X and Y fans.	
RSI/SIN-Real Ray Trace.....	18-165
The Real Ray Trace feature (RSI/SIN) allows you to trace single rays in designated wavelengths, with user-defined formatting.	
THO - Third Order Aberrations	18-181
The Third Order Aberrations (THO) feature allows you to perform third-order surface-by-surface contributions and sums.	
Macros to Perform Diagnostic Analyses	18-183
Several CODE V supplied macros provide useful diagnostic analyses. This section provides a quick summary of the macro capabilities, and points you to more information about how to use them.	

Options

ANA - First/Third Order Analysis	18-7
BEA - Gaussian Beam Trace	18-27
CAT - Catseye Plot	18-39
FIE - Field Curves	18-43
FIO - Paraxial Ray Trace	18-59
FMA - Field Map	18-63
FOO - Footprint Plot	18-91
FOV - Biocular Field of View Plot	18-113
Macros to Perform Diagnostic Analyses	18-183
PMA - Pupil Map	18-127
RIM - Ray Aberration Curves/OPD Aberration Curves	18-155
RSI/SIN- Real Ray Trace	18-165
THO - Third Order Aberrations	18-181

Figures

ANA - First/Third Order Analysis

Figure 1. Default ray grid for ANA; RAYS	18-15
Figure 2. Diagram of general ray in ANA	18-15
Figure 3. Ray trace output data	18-17

CAT - Catseye Plot

Figure 1. Plot Codes	18-41
Figure 2. CAT output for three surfaces	18-42

FIE - Field Curves

Figure 1. FIE plotted output	18-50
Figure 2. Enhanced FIE plotted output	18-51
Figure 3. FIE;FFD plotted output; centered triplet	18-53
Figure 4. FIE;FFD plotted output; decentered triplet	18-54
Figure 5. CODE V distortion calculation	18-57

FMA - Field Map

Figure 1. Layout of sample volume hologram.....	18-84
Figure 2. Plot of Bragg diffraction efficiency using FMA	18-85
Figure 3. Plot of two-dimensional distortion using FMA	18-86
Figure 4. Full field display (FFD) of coma with and without anamorphic scaling (ASC)	18-87
Figure 5. CODE V uncalibrated distortion calculation	18-89
Figure 6. Schematic of distortion calibration	18-90

FOO - Footprint Plot

Figure 1. Example of FOO output showing optional linestyles and legends	18-107
Figure 2. Example of FOO output for system	18-108
Figure 3. Example of FOO showing grid mode (BOU N)	18-109
Figure 4. Example of FOO showing surface conflict	18-110

FOV - Biocular Field of View Plot

Figure 1. FOV option determines field of view coverage as seen from each eye location	18-113
Figure 2. Example of FOV option with a biocular	18-122
Figure 3. FOV plot with line styles and legends	18-123
Figure 4. Layout of dual glazed HUD	18-125
Figure 5. FOV plot for dual glazed HUD	18-126

PMA - Pupil Map

Figure 1. Exit pupil plane coordinates used for Zernike fits	18-142
Figure 2. Exit pupil sphere coordinates used for Zernike fits	18-143
Figure 3. PMA perspective plot	18-146
Figure 4. PMA contour plot with numbers suppressed	18-147
Figure 5. PMA raster display output	18-148

RIM - Ray Aberration Curves/OPD Aberration Curves

Figure 1. Default RIM plot for Cooke triplet	18-161
Figure 2. Enhanced RIM output	18-162
Figure 3. Possible input changes for a zoom lens	18-163
Figure 4. Exclusion of blocked rays from RIM output	18-164

RSI/SIN-Real Ray Trace

Figure 1. Data inputs for SIN	18-167
-------------------------------------	--------

Examples

ANA - First/Third Order Analysis

Example 1. Third-order output.....	18-14
Example 2. Ray trace analysis output.	18-16
Example 3. Surface-by-surface ray trace	18-17
Example 4. Higher-order analysis.	18-21

BEA - Gaussian Beam Trace

Example 1. Simple focusing lens.....	18-33
Example 2. A faster simple focusing lens.....	18-35
Example 3. Tilted anamorphic system.....	18-36
Example 4. Fiber optics component.....	18-37

CAT - Catseye Plot

Example 1. Catseye Plot of wide angle lens with critical surfaces shown (Figure 2).	18-42
--	-------

FIE - Field Curves

Example 1. The minimum input possible for both listing (Table 1) and plotted output (Figure 1) for a Cooke triplet lens.....	18-50
Example 2. Add LSA (longitudinal spherical aberration) to the plot and user-selected plot scales for the Cooke triplet (Figure 2).	18-51
Example 3. Use the LIN command, to obtain a listing of F-theta linearity (Table 2).	18-52
Example 4. Full-field display of centered triplet (Figure 3).	18-53
Example 5. Full-field display of the decentered triplet (Figure 4).....	18-54
Example 6. One table (of the 15 generated) corresponding to one row (constant Y field points) of the Figure 4 input (Table 3).	18-55

FMA - Field Map

Example 1. 2D field display of diffraction sine wave MTF	18-80
Example 2. Circular Field	18-81
Example 3. 1D field display of diffraction sine wave MTF	18-82
Example 4. Full field display of diffraction efficiency.	18-85
Example 5. Full field display of distortion.....	18-86
Example 6. Full field display of third-order coma, FRINGE Zernikes Z7 and Z8.....	18-87

FOO - Footprint Plot

Example 1. Footprint of first surface of standard Double Gauss, with selected linestyles and a legend for each.	18-107
Example 2. Boundary Mode	18-108
Example 3. Grid Mode.....	18-109
Example 4. Clearance Checking	18-110

FOV - Biocular Field of View Plot

Example 1. A 100 mm Focal Length Biocular.	18-121
Example 2. The effect of motion of eyes in an “eye box”	18-123
Example 3. Dual combiner conventional Head-Up Display (HUD).....	18-124

PMA - Pupil Map

Example 1. Pupil map (oblique projection) of a Cassegrain system, including obscuration.	18-146
Example 2. Pupil map (contour) of the same Cassegrain system, including obscuration.	18-147
Example 3. Same as Example 2 with data drawn as interference fringes.	18-148
Example 4. Interferometric Analysis - using standard Zernike polynomial (output not shown).....	18-149
Example 5. Listed output for PMA.	18-149

RIM - Ray Aberration Curves/OPD Aberration Curves

Example 1. The minimum input possible (default run) for a Cooke triplet lens.	18-161
Example 2. Typical input changes for a Schmidt telescope including an aspheric element.	18-162
Example 3. Some possible input changes for a zoom lens (the combination of commands is fairly arbitrary, but illustrates how commands can be changed by zoom position).	18-163
Example 4. Excluding plotting of rays clipped by active apertures or obscurations.....	18-164

Tables

FIE - Field Curves

Table 1. FIE listed output	18-50
Table 2. FIE;LIN listed output.....	18-52
Table 3. FIE;FFD listed output (partial)	18-55

